

Slayer Special Materials Care Instructions

WARNING!

Bleach and other harsh chemicals/solvents can discolor or damage the finish on powder coated, wood, and duratex surfaces
Abrasives - even soft plastic scouring pads - can leave light scratches in powder coating, aluminum, stainless, copper, gold, wood, duratex surfaces.

POWDER COATING

- Microfiber towel + mild cleanser, soap & water
- Denatured alcohol, rubbing alcohol, or paint-safe degreaser for deep cleaning/degreasing
- Same as automotive paint care products

BARE METAL, PLATED, ANODIZED

- Stainless steel, aluminum, chrome, copper, nickel, 24k gold panels and components
- Microfiber towel + Windex to clean
- Meguiar's Quik Wax (or similar high quality automotive spray wax) to polish
- **Do not use polish on textured or anodized surfaces**

WOOD FINISH

- Espresso, Single Group, Steam LP with sapele -steam, hot water, and brew actuator handles, portafilter handles, side panels
- Microfiber towel + mild cleanser (soap & water). Dry immediately!
- Buff with OSMO Polyx-Oil (satin) or mineral oil to repair scratches or discoloration
- **Do not submerge or leave moisture on surfaces - dry immediately**
- **Bleach and other harsh solvents will discolor and damage finish**

ONYX DURATEX

- Steam LP standard configuration-steam actuators, brew actuators, portafilter handles
- Microfiber towel + mild cleanser (soap & water)
- Denatured alcohol or rubbing alcohol for degreasing
- Buff with mineral oil for scratches or dull discolored spots
- **Bleach and other harsh solvents will discolor and damage finish**

OVERMOLDED RUBBER (NEOPRENE)

- Steam EP - steam actuators, portafilter handles
- Microfiber towel + mild cleanser (soap & water)
- **Bleach and other harsh solvents will degrade neoprene causing it to erode**